

Customer Services Bulletin Alicanto Grande Free Standing Table Modification 21/07/2020



Dear Colleague,

Following customer feedback, the free standing table now supplied with all Alicanto Grande models has a larger surface area as a result of the addition of two folding extension flaps.

As and when owners of earlier production models request this upgrade, please submit the appropriate warranty claim for parts and labour using the following details:

There are two table kits available as follows:

Alicanto Grande – Sintra & Porto models

• Alicanto Grande – Estoril models

Labour

Kit Part No. **2990590** Kit Part No. **2990591** Warranty Code. **9999083**

Standard operation time allowance

1 hour

Please refer to the Standard Operating Procedure Z-SOP-RPC-P-SP-0012 attached below for more information on how to modify the table accordingly.

Should you have any queries with the above please contact us customerservices@baileyofbristol.co.uk

Best regards

Dave Evans Head of Customer Services



Alicanto Free Standing Table Revision

Z-SOP-RPC-P-SP-0012

Document Revision History								oct.	ud:
Revision	Reason For Change				Date	Ву	Product Affected:		eu.
01		Initial Write Սր)				Model Rar	200	
02							IVIOGEI Nai	ige	
О3							Log Catego	orv	
04							Log Catego	O1 y	•
O 5							Information S	Sou	rce.
О6							informations	<i></i>	
07							Initial Release	Διι	thor:
08							micial Herease		
O 9							Latest Release	e D	ate:
010								_	
Document Approval & Sign Off								Additional Training Req:	
Revision	E.H.S.	Production	N.P.I.	Qua	ality	Log Admin	8 4		,
01								Pr	oduction Hand Over
02									
О3							Production Line	e:	
04									
05							Station No:		
06									
07							MTL Name:		
08							WITE Hame.		
O 9							MTL Signature	::	
010							0		
PPE Requirements Contained within this document:									Additional Information:
								*	Ensure Any Sealant/Adhesive Being Us Is Within It's Expiry Date.
7	W							*	
	Int American							*	
								*	

Note: Inspect all co	mponents for damage before const	ruction and keep all benches plus v		s a reduction to risk.									
			*										
		Miles No De surius d	*										
	What's Required TOOLING												
No2 Pozi Drive Screwdriver	Description	Description	Description	Description									
	·	·											
Description	Description	Description	Description	Description									
·	·	·	·										
		What's Required											
		PARTS											
Description	Description	Description	Description	Description									
Description	Part No:	Part No:	Part No:	Part No:									
Description	Description	Description	Description	Description									
Part No:	Part No:	Part No:	Part No:	Part No: Dependant on type/mod									

Operator Reference Sheet

Revision:

These attachments can be removed from the SOP & used line side for product change over information

1) Table Upgrade Kit: Check all parts are present and undamaged.

Contents: a) Large Centre Table Base, b) Table Side Extensions, c) Support Hinges, d) Table Hinge Fixing Screws

b) 1XZ0116 - Table Side Extensions Quantity 2 off



a) 1XZ0115 - Centre Table Base Quantity 1 off

c) 1XZ0117 - Support Hinges Quantity 4 off



d) 1490461 - Screw - No6 x 5/8" CSK Pozi Self Tapping S/S Ouantity 24 off




NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL


Operator Reference Sheet

These attachments can be removed from the SOP & used line side for product change over information





3) Remove 6 off fixing screws from table legs



NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

Revision: 1

These attachments can be removed from the SOP & used line side for product change over information



4) With screws removed lift off the table legs and place safely aside for refitting to new table





NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

Revision: 1

These attachments can be removed from the SOP & used line side for product change over information

5) Place main table section face up on clean work bench and then position the table extensions next to main section aligning the hinge bracket cutouts






NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

Revision: 1

These attachments can be removed from the SOP & used line side for product change over information

6) Locate each of the 4 hinges in turn into the cutouts, note hinge will be a push fit.






NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

These attachments can be removed from the SOP & used line side for product change over information




7) fit and secure 6 off hinge fixing screw 1490461, for each of the 4 hinges in turn.



Page 8 of 17








NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

Revision: 1

These attachments can be removed from the SOP & used line side for product change over information





NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

These attachments can be removed from the SOP & used line side for product change over information



9) Fold both extensions into closed position


Page 10 of 17 Z-SOP-STD-P-SP-0000 - 01



NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

These attachments can be removed from the SOP & used line side for product change over information

Operator Reference Sheet Revision:







NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

These attachments can be removed from the SOP & used line side for product change over information








NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

These attachments can be removed from the SOP & used line side for product change over information






NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

Revision: 1

These attachments can be removed from the SOP & used line side for product change over information



Page 14 of 17 Z-SOP-STD-P-SP-0000 - 01



14) Fold table leg with turn buckle first

NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

These attachments can be removed from the SOP & used line side for product change over information



Revision:

Page 15 of 17 Z-SOP-STD-P-SP-0000 - 01







NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL

Operator Reference Sheet

These attachments can be removed from the SOP & used line side for product change over information

15) Fold 2nd table leg then rotate turn buckle 180 degrees to lock legs in closed position

Note: Inspect all components for damage before construction and keep all benches plus work stations clean, prevention is a reduction to risk.



NOTE: It is recommended to keep any visuals or information supplied in a station folder kept by the MTL